4. Монтаж остекления

Стекло вкладывается в щель сверху полотна – для щитовых дверей, для рамочно-филёнчатых монтаж стекла производится путём вставки в проём и последующей фиксацией раскладки при помощи соответствующих гвоздей (шпилек).

5. Эксплуатация и уход

Эксплуатация изделий согласно СТБ 1138-98, СТБ 1074-97 нормальной влагостойкости для помещений с нормальным и сухим режимами, должна осуществляться в помещениях со следующими условиями согласно СНБ 2.04.01
- при t>+24°С с относительной влажностью 40-50%;
- при t от +12 до +24°С с относительной влажностью 40-60%;
- при t до +12°С с относительной влажностью 60-75%.

Минимальная температура эксплуатации продукции ОДО "Беллесизделие" +5°С.
При этом не допускаются резкие колебания данных параметров.

Во время эксплуатации лакированные поверхности со временем могут изменить цвет не только от климатических характеристик и условий окружающей среды, характера ухода, но самое главное от степени воздействия на них света.

В процессе эксплуатации дверных полотен, коробки, наличника - не должны применяться методы воздействия на них, вызывающие их термическое и механическое повреждение.

Мыть двери водой и моющими средствами на водной основе запрещается.
Так как капли влаги полностью не стекают с плоскости дверного полотна и скапливаются в зонах декоративного профиля, влага постепенно проникает в древесину. Это приводит к ее набуханию а, следовательно, к деформации, трещинам и отслаиванию лакокрасочного покрытия.

При уходе за изделиями для придания поверхности блеска и свежести могут применяться все типы аэрозолей по уходу за деревянной мебелью (согласно рекомендаций по использованию аэрозолей).

Открытие и закрытие двери в процессе эксплуатации не должно производиться способами, вызывающими повреждение дверного полотна, коробки, наличника, облицовочного материала и лакокрасочного покрытия.

6. Гарантии изготовителя

Внешний вид и комплектность изделия должны быть проверены покупателем при покупке до монтажа фурнитуры. В дальнейшем претензии по внешнему виду и комплектности не принимаются.

Гарантийный срок эксплуатации изделий - 24 месяца со дня изготовления, но не менее 12 месяцев с даты продажи. Производитель не отвечает за недостатки товара, возникшие после его передачи потребителю вследствие нарушения потребителем правил эксплуатации и ухода, а также в результате естественного износа (потертости; царапины; вмятины; сколы; расшатывание петель, замков, ручек, изменение цвета).

Для предъявления претензий на товар необходимо предоставить настоящее "Руководство по транспортировке, хранению, монтажу и эксплуатации дверей", копию товарного чека и письменное заявление.

Производитель оставляет за собой право вносить изменения в технологию и дизайн своих изделий, а также используемые материалы.

Изделия, изготовленные ОДО «Беллесизделие»», признаны годными к эксплуатации и соответствуют СТБ 1138-98 "Двери и ворота для зданий и сооружений. Общие технические условия" и СТБ 1074-97 "Детали профильные из древесины и древесных материалов для строительства Технические условия".

Пусть наши двери долго радуют Вас, даря счастье и уют Вашему дому!

BELWOODDOORS

www. belwood.ru

ОДО "Беллесизделие"
РБ, г. Минск, ул. Промышленная, 10

BELWOODDOORS

ПАСПОРТ ИЗДЕЛИЯ

BELWOODDOORS

РУКОВОДСТВО ПО ТРАНСПОРТИРОВКЕ, ХРАНЕНИЮ, МОНТАЖУ И ЭКСПЛУАТАЦИИ ДВЕРЕЙ

гарантия 2 года

- монтаж дверей
- рекомендации по установке
- хранение, эксплуатация, уход
- гарантийные обязательства

1. Хранение

Хранить дверные полотна необходимо в заводской упаковке.

При хранении дверей должны быть приняты меры для предохранения их от механических повреждений, загрязнения, увлажнения, воздействия атмосферных осадков, от попадания прямых солнечных лучей, от воздействия температур менее 5°С и более 40°С. Не допускается хранение двери вблизи отопительных приборов. Условия хранения должны обеспечивать нормативную влажность изделий в соответствии с СТБ 1138-98.

Во избежание деформации дверных полотен их необходимо хранить:
- в горизонтальном положении на ровной поверхности в стопе;
- между полотнами должны находиться равные по толщине прокладки;
- в сухом проветриваемом помещении относительной влажностью воздуха 30-65%;
- расстояние до приборов отопления должно быть не менее 0,5 метра.

Не допускается хранение дверей вертикально, прислонёнными к опоре.

2. Транспортировка

Двери транспортируются всеми видами транспорта в соответствии с действующими требованиями СТБ 1138-98.

Двери должны транспортироваться в контейнерах, на поддонах или других устройствах, обеспечивающих их защиту от повреждений, увлажнения, атмосферных осадков, попадания прямых солнечных лучей.

Дверные полотна, а также дверные коробки и доборные элементы могут транспортироваться в горизонтальном положении на поддонах.

Переносить двери следует на весу или с помощью вспомогательных механических средств (тележка и т.п.). Кантовать и перемещать волоком – не допускается

3. Монтаж в дверной проём

Установку дверного блока должны производить специалисты, прошедшие обучение и имеющие соответствующую квалификацию.

Несоблюдение инструкций может привести к порче дверей а, следовательно, аннулирует гарантии производителя.

Установка дверного блока должна осуществляться в помещении с температурно-влажностными показателями указанными в п.5.

Монтаж дверей в строящемся либо ремонтируемом помещении допускается проводить только после окончательного высыхания всех строительных материалов;

Рекомендуется, что бы двери находились в помещении (где они будут установлены) в течение 3-4 дней до дня монтажа, для выравнивания параметров влажности и температуры.

При установке дверной коробки может применяется монтажная пена. Запрещается использовать цементные смеси, а также смеси на водной основе для предотвращения коробления изделия.

ПРОДУКЦИЯ СЕРТИФИЦИРОВАНА

www. belwood.ru

4. Glazing installation

The glass is embedded in the slot at the top of the door leaf - for the shield doors, for the framework-panel ones the glass assembly is performed by inserting into the opening and the subsequent fixation of layouts using appropriate nails (pins).

5. Operation and maintenance

Operation of products according to the STB 1138-98, STB 1074-97 in conditions of normal moisture resistance for premises with normal and dry regimes should be carried out in rooms with the following conditions according to SNB 02.04.01:
- At t> +24°C with relative humidity 40-50%;
- At t from +12 to +24°C with relative humidity 40-60%;
- At air t up to +12°C with relative humidity 60-75%.

Minimum operating temperature of products manufactured by ALC "Bellesizdelie" is +5°C.
It is not allowed any sudden changes in these parameters.

During the maintenance of the varnished surface over the time it can change the color, not only because of the climatic characteristics and environmental conditions, the character of care, but most importantly because of the degree of light exposure.

During the maintenance of door leaves, door frames andlining, it is not allowed to apply any methods of influence on them causing their thermal and mechanical damage.

Washing the door with water and detergent on the basis of water is prohibited, as drops of water do not completely drain from the plane of the door leaf and accumulate in the areas of the decorative profile. This leads to itsswelling, hence, deformation, cracking and peeling of the paintwork.

When maintenance of the products to make the surface shine and look fresh, all types of aerosols for wood furniture care (as per the recommendations on the use of aerosols)can be used.

Opening and closing the door during operations should not be done in ways that can cause damage to the door leaf, frame, lining, facing material and paint-and-lacquer coating.

6. Manufacturer's warranty

The appearance and completeness of the item should be inspected by the Buyer when purchasing before the installation of the furniture. Further claims on the appearance and completeness of the item are not accepted.

The warranty period is 24 months from the date of manufacture, but not less than 12 months from the on-sale date. The manufacturer is not responsible for the defects of the item that arose after its transfer to the Buyer because of violations of rules of operation and customer care, and as a result of normal wear and tear (wear, scratches, dents, chips, loosening hinges, locks, handles, color change).

For the claim on the products you need to present the current "Guideline on doorstransportation, storage, mounting and maintenance", a copy of your sales receipt and a written statement.

We reserve the right without notice to change the technology and design of our products, as well as the materials used.

Products manufactured by ALC "Bellesizdelie", declared unfit for use and comply with STB 1138-98 "The doors and gates to buildings and facilities. General technical conditions", STB 1074-97 "The details of the profile and wood construction materials.Specifications".

Let our doors please you for a long time, giving happiness and comfort to your home!

BELWOODDOORS

www. belwood.ru

Belwooddoors Additional Liability Company
10, Promyshlennaya St., Minsk, Republic of Belarus

BELWOODDOORS

Data Sheet

BELWOODDOORS

GUIDANCE ON DOORS TRANSPORTATION, STORAGE, MOUNTING AND MAINTENANCE

2 year guarantee

- Installation of doors
- Recommendations on installation
- Storage, operation, leaving
- Guarantee certificates

1. Storage

Keep door leaves in original packaging.

When keeping doors, they shouldbe protected from mechanical damage, pollution, humidity, precipitation effect of a direct sunlight, from the effects of temperatures less than 5°C and 40°C. It is not allowed to keep the doors near heaters.
Storage conditions should provide regulatory moisture of the products in accordance with STB 1138-98.

In order to avoid deformation of door leaves they should be stored:
- horizontally on a flat surface in a stack;
- between the door leaves there should be a packing equal to the thickness;
- in a dry ventilated space with a relative humidity of 30-65%;
- the distance to the heating devices should not be less than 0.5 meters.

Do not store doors upright, leaning against the pillar.

2. Transportation

Doors are transported by all modes of transport in accordance with the requirements of STB1138-98.

Doors should be transported in containers, pallets or other devices to protect them from damage, moisture, direct sunlight precipitation.

Door leaf and door frames, and additional elements can be transported horizontally on pallets.

Wrap the door suspended or with the help of auxiliary mechanical means (truck, etc.). It is not allowed to turn over and drag.

3. Mounting into a doorway

Installation of a door unit should be carried out bytrained professionals having the proper skills.

Failure to comply with the instructions can result in damage to doors and, hence, it avoids the manufacturer's warranty.

Installation of a door unit should be carried out in a room with temperature and humidity levels stated in point 5.

Mounting of the doors in newly built or repaired premises is admitted only after the final drying of building materials.

It is recommended that the doors are kept in the room (where they are to be installed) for 3-4 days before the mounting to align the parameters of humidity and temperature.

When installing a door frame,polyurethane foam can be used. Do not use any cement mixtures and mixtures of water-based products to prevent warping.

Production is certificated

www. belwood.ru